

## F599 Heavy Duty Spray Adhesive

**Versatile spray adhesive** for bonding a **wide range of floorcoverings.**

- **High Adhesives Content**
- **Excellent Bond Strength**
- **Quick Drying**
- **Easy to Use**

### Description:

F599 is a versatile spray adhesive. Its high solids/low solvent formula produces a quicker, stronger, more aggressive bonding system that outperforms conventional aerosol adhesives.

### Uses:

F599 Contact Spray Adhesive is suitable for the permanent bonding of carpets, carpet tiles, cork, paper, underlay, felts and much more.

Not suitable highly plasticised Vinyls & PVC floorcoverings.

### Sub-Floors:

F599 is suitable to bonding to Concrete bases, cement screed, smoothing & levelling underlayment, flooring grade chipboard, hardboard, plywood, stone, terrazzo, quarry tiles, ceramic, brickwork and plaster. It is also suitable for bonding to metal, glass and most plastics.

### Specification:

Adhesive Type:	SBR Resin
Colour:	Light Beige
Flashpoint:	Highly Flammable
Coverage:	Approximately 1.5m <sup>2</sup> per 500ml can onto a dual surface application
Application Temperature:	+5°C - +30°C
Drying Time:	Approx. 10 Minutes depending on temperature, humidity & subfloor
Storage & Shelf Life:	12 months in original, unopened container stored between +5°C and +25°C.
Container Size:	500 ml Can



### Directions for Use:

#### IMPORTANT

Before using F599 Heavy Duty Spray Adhesive please refer to the safety guide and data sheet available at [www.floorwise.co.uk](http://www.floorwise.co.uk)

All phases of the installation should comply with the latest editions of the following standards:

- BS 8102 Code of Practice for the protection of buildings against water from the ground.
- BS 5325 Code of Practice for the installation of textile floorcoverings.
- BS 8203 Code of Practice for the installation of resilient floorcoverings.

### Preparation:

Surfaces to be bonded should be clean, dry and dust free.

Shake can well before use.

### Application:

Spray an even coat of adhesive onto both surfaces. Allow adhesive to become touch dry, so that it does not transfer to finger, which can be almost immediately.

Press floorcovering firmly into place, which will bond immediately.

Allow approximately 10 minutes for adhesive to set.

After use invert can and press nozzles to clear adhesive from spray tip.

### Cleaning:

Remove any over spray immediately with Floorwise solvent cleaner or minimum of white spirit.

## F599 Heavy Duty Spray Adhesive

### Safety Guidance:

<b>DANGER</b>	<b>F599 Heavy Duty Spray Adhesive</b>	<b>UN1950</b>
 	<b>Contains: DICHLOROMETHANE</b>	
<p><b>Hazard Statements</b>  Extremely flammable aerosol.  Pressurised container: may burst if heated  Causes skin irritation  Causes serious eye irritation  May cause drowsiness or dizziness.  Suspected of causing cancer</p> <p><b>Precautionary Statements</b>  Keep away from heat/sparks/open flames/hot surfaces.  No Smoking  Do not spray on an open flame or other ignition source.  Pressurised container: Do not pierce or burn, even after use.  Use only outdoors or in a well-ventilated area.  Wear protective gloves/protective clothing/eye protection/face protection.  Protect from sunlight. Do not expose to temperatures exceeding 50°C.  Repeated exposure may cause skin dryness or cracking.</p> <p><b>KEEP OUT OF REACH OF CHILDREN</b></p> <p>Dispose of contents/container in accordance with national regulations</p>		
<b>500ml</b>	Label in accordance with (EC) No. 1272/2008	



A full materials safety data sheet relating to this product is available at [www.floorwise.co.uk](http://www.floorwise.co.uk)

This product data sheet is provided for guidance only. For further information and advice on application, or if in any doubt as to the suitability of the product for the installation, please contact our Technical Department for advice.