

## F597 Heavy Duty Spray Adhesive

A versatile **dichloromethane free** spray adhesive ideal for bonding an **extensive range** of materials and **floorcoverings**.

- **High Adhesives Content**
- **Excellent Bond Strength**
- **Quick Drying**
- **Easy to Use**

### Description:

F597 is a versatile spray adhesive. Its high solids/low solvent formula produces a quicker, stronger, more aggressive bonding system that outperforms conventional aerosol adhesives.

### Uses:

F597 Contact Adhesive is suitable for the permanent bonding of carpets, carpet tiles, cork, paper, underlay, felts and much more.

F597 is not suitable for highly plasticised Vinyl or PVC floorcoverings.

### Sub-Floors:

F597 is suitable for bonding to Concrete bases, cement screed, anhydrite screed, smoothing & levelling underlayment, flooring grade chipboard, hardboard, plywood, stone, terrazzo, quarry tiles, ceramic, brickwork and plaster.

It is also suitable for bonding to metal, glass and most plastics.

### Specification:

Adhesive type:	SBR Adhesive
Colour:	Light Beige
Flashpoint:	Highly-Flammable.
Coverage:	Approximately 3m <sup>2</sup> per can.
Application Temperature:	+5°C – +25°C.
Working Time:	Approximately 10 Minutes depending on temperature, humidity & subfloor.
Storage & Shelf Life:	12 months in original, unopened can between +5°C and +25°C.  Store in accordance with requirements of Petroleum Regulations.
Container sizes:	500ml Can.



### Directions for Use:

#### IMPORTANT

Before using F597 Heavy Duty Spray Adhesive please refer to the safety guide and data sheet available at [www.floorwise.co.uk](http://www.floorwise.co.uk)

All phases of the installation should comply with the latest editions of the following standards:

- BS 8102 Code of Practice for the protection of buildings against water from the ground.
- BS 5325 Code of Practice for the installation of textile floorcoverings.
- BS 8203 Code of Practice for the installation of resilient floorcoverings.

### Preparation:

Surfaces to be bonded should be clean, dry and free from dust.

Shake can well before use.

### Application:

Spray an even coat of adhesive onto both surfaces.

Allow adhesive to become touch dry, so that it does not transfer to finger, which can be almost immediately.

Press the floorcovering firmly into place which will bond immediately.

Allow approximately 10 minutes for the adhesive to set.

After use invert the can and press the nozzle to clear adhesive from the spray tip.

### Cleaning:

Remove any overspray immediately with Floorwise solvent cleaner or the minimum of white spirit.

### Safety Guidance:

F597 HEAVY DUTY SPRAY ADHESIVE	
<p><b>DANGER</b></p> 	<p>Extremely flammable aerosol. Pressurised container: may burst if heated. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Do not spray on an open flame or other ignition source. Do not pierce or burn, even after use. Avoid breathing vapour/spray. Use only outdoors or in a well-ventilated area. Wear protective gloves/protective clothing/eye protection/face protection. Protect from sunlight. Do not expose to temperatures exceeding 50°C/122°F. Dispose of contents/container in accordance with national regulations. Keep out of the reach of children. A full safety data sheet relating to this product is available at <a href="http://www.floorwise.co.uk">www.floorwise.co.uk</a></p>
<p><b>500ml UK CA 650</b></p>	



A full materials safety data sheet relating to this product is available at [www.floorwise.co.uk](http://www.floorwise.co.uk)

This product data sheet is provided for guidance only. For further information and advice on application, or if in any doubt as to the suitability of the product for the installation, please contact our Technical Department for advice.